


Installation Instruction - SLAL1 LED Area Light

Warning, cautions and operating instructions

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts, abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.
- Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.
- For The installation: If you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
- In order to use this product more efficiently and safely, please clean and check it regularly (once every six months).

Warning: Risk of fire or electrical shock

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- Make all electrical and grounded connections in accordance with the National Electrical Code and any applicable local code requirements.
- All wiring connections should be capped with UL approved wire connectors.
- SUITABLE FOR WET LOCATIONS / CONVIENT AUX EMPLACEMENTS MOUILLÉS
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE
 INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND
 OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTI-NENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS.






Starco Lighting Inc. 2495 Main Street, Suite#218, Buffalo NY 14214 Tel: 716-931-9322 www.starcous.com

Installation Instruction - SLAL1 LED Area Light


6 Mounting Brackets



The Installation must be carried out by a qualified electrician.




SLAL1 LED Area Light with SLAL-MK1 Mount






SLAL1 LED Area Light with SLAL-MK2 Mount




2CO


I.Use a wrench to unscrew the screws of mount and fixing base to separate mount and fixing base; Unscrew the two screws of mount with a wrench, remove the screws and the iron bar, unscrew the cover screw with a screwdriver, and open the cover plate.




2. Pass the fixture's AC input wires through the fixing base and then tighten screws to assemble fixing base to fixture body, The screws are threaded through the cover plate and bracket secured to the fixture.




3 . After the fixture input wires passes through the mount, assemble the mount and fixing base. Tighten the mount and fixing basewith a wrench and screw.



4. After the bolts pass through the lamp and post, screw the bolts on the sticking strips with a wrench. The lamp is fixed on the fixture post.




5. When installing to round pole, please remove the rubber gasket.




8. Loose the locking bolt by a wrench to adjust the angle. The angle range is 15°. Then tighten the locking bolt.




SLAL1 LED Area Light with SLAL-MK6 Mount







3. Tighten the bolts using a wrench after the cable is through the fixing base.




2. Pass the cable in the post through the mount.




4. Tighten the 4 screws on the mount using a wrench.





7. Close the cover and tighten the screws with a screwdriver, as shown in Figure 22



8. Loosen the locking bolt in the slip-fitter by a wrench to adjust fixture to a appropriate angle (adjustable angle range 180°), then tighten the locking bolt.

iaht with SI AL-MK3 Mount SI Area






Fig 24

1. Use a wrench to unscrew the bolts and remove the strips. Use screwdriver to loose the screws to open the cover plate, as shown in Figure 24.



2. After the bolt passes through the bracket and the post, screw the screws on the sticking strips with a wrench. The bracket is installed onto the post, as shown in Fig. 25.





3. When installing to round pole, please remove the rubber gasket.




Fig 26

4. Install the fixture onto the bracket, and then tighten the bolts with a wrench, as shown in Fig. 27.









SLAL1 LED Area Light with Sensor

